

# Repair Reduce Prime

Concrete Floors

# Self-levelling Flooring Preparation



# abe.<sup>®</sup>rep FS (Fast Setting)

Rapid fixing mortar for concrete floors.

#### USES

For smaller patch type repairs offering a minimal amount of downtime prior to the application of self-levelling underlayments and/or screeds.

#### ADVANTAGES

- Ready-to-use
- Dustless, >80%
- Fast acting
- Chloride free
- Constant



## abe.®cote vapour barrier

Epoxy resin vapour barrier for concrete floors.

#### USES

Moisture vapour barrier and surface primer.

#### **ADVANTAGE**S

- Easily applied
- Reduces water vapour permeability rates through concrete
- Decreases outgassing through concrete

### abe<sup>®</sup> keying slurry

Acrylic based primer or self-levelling screed.

#### USES

For priming concrete screed sub-floors, epoxy coatings, smooth surfaces, and impermeable surfaces like tiles prior to the application of **abe.**®screed SLCP 25.

#### ADVANTAGES

- Ease of application
- Improves adhesion to substrate
- Reduces surface absorbency
- Suitable for internal & external applications
- Non-toxic

